



Sensible Products for a Non-Sensible World

BlackOut® Maintenance and Options for Use



No Lubricants Necessary

Laboratory studies and field evaluations, have indicated that very few, if any, bed bugs can escape BlackOut with no lubricants in the trap well. Therefore, BlackOut can be installed in a home without lubricants added to the trap wells.

*While it is not suggested, if you're interested in using additives, such as talcum powder, visit www.SenSciOnline.com/BlackOutTalc for proper usage directions.



Cleaning to Prevent Escape

BlackOut's recommended maintenance is cleaning the trap well with a microfiber cloth every 2-4 weeks to clear any dust out of the trap wells. Dust accumulation can be similar to rocks on a rock-climbing wall for bed bugs to escape. To help prevent bed bugs from escaping, thoroughly clean the inner wells with a microfiber cloth.

IMPORTANT:

Only microfiber cloths should be used to reduce scratching of the trap well.



Use Activ Lure to Increase Trap Catch

To increase catch rate of BlackOut, simply add the SenSci Activ® Bed Bug Lure to attract up to twice as many bed bugs to the interception device.



351 Lawrence Station Rd. Lawrenceville, NJ 08648
SenSciOnline.com



Sensible Products for a Non-Sensible World

BlackOut® Directions for Use



Place one BlackOut device under each of the legs of beds, couches or other furniture of concern for bed bugs.



If furniture leg does not fit in the center well of the device, place the device next to each of the legs of the furniture.



If the furniture is resting on the floor, place one BlackOut device every three feet on the floor around the perimeter of the furniture or at the four corners of the bed.

For an informative video tutorial on BlackOut, visit <https://youtu.be/zgpkOlrumFw>



351 Lawrence Station Rd. Lawrenceville, NJ 08648
SenSciOnline.com